

Rice Polishing Machine



MSMPGW1252SWISS Rice Polishing Machine:

Description:

The **horizontal double roll polishing machine** features an upper and lower structure that allows for parallel or series operation. It is known for its modern appearance, high output, compact size, and efficient design. The machine uses high air pressure to spray water in mist form into the polishing chamber, ensuring an even and stable water application on the rice grains. This process, combined with light friction between the rice grains and the roller, results in a smooth and clean surface. It also includes an automatic water inlet control system and stainless steel polishing rollers for enhanced durability and hygiene.

Specification:

- **Model:** MSMPGW1252SWISS
- **Capacity:** 1.0 to 2.0 tons per hour
- **Power:** 30 kW
- **Dimensions (L x W x H):** 2000 x 500 x 2200 mm

This rice polishing machine is designed for high-efficiency rice processing with a focus on quality and longevity.